



Microsoft®  
**Xbox 360**®  
Controller for Windows®

PC • USB



**Microsoft®**



# Microsoft® **Xbox 360®** Controller for Windows®

## Precisely what you need for PC and Xbox® gaming

Play with confidence with this responsive, ergonomic controller. It works on either your PC or Xbox to give you the ultimate gaming experience.

## Features

### Play in comfort

A compact, ergonomic shape lets you play comfortably for hours on your PC.

### Feel the action

Vibration feedback gives you a riveting gaming experience.

### PC gaming at its best

Precise thumb sticks, two pressure-point triggers, and an 8-way directional pad help you stay in control.



### System Requirements

 Windows® 7, Windows Vista®, Windows XP SP2 (excluding 64-bit)

 Pentium 300 MHz or higher

 128 MB

 CD drive/Powered USB port

 30 MB

**You must accept License Terms for software download.**

Internet access required for certain features. Local and/or long-distance telephone toll charges may apply.

© 2011 Microsoft Corporation.

The data contained herein is subject to change. This document is provided for informational purposes only. Microsoft makes no warranties, expressed or implied, in this document.  
1210\_FT0227RTL