

INTRODUCING THE



QUICK-FLIP™ CORNER

Case corner exposes camera to attach your oloclip without removing the entire case.

QUICK-FLIP™ PHOTO CASE

SHUTTER RELEASE

Case corner rotates to create an easy to use shutter release with the + button on your device.

A QUICK-FLIP™ PHOTO CASE & PRO-PHOTO ADAPTER

This sleek protective case for the iPhone 5 & 4S/4 is specially designed to reveal a corner of the phone without removing the case giving you quick access to use your oloclip 3-in-1 lens.

COLD SHOE MOUNT

For lights or microphone, etc.

PRO-PHOTO ADAPTER

Slides onto Quick-Flip™ Photo Case providing three pro-photo mounts.

AVAILABLE IN



TRANSLUCENT
BLACK



WHITE

TRIPOD MOUNTS

Standard threaded mount-points.



**THE
COMPLETE
PHOTO
SOLUTION***
olloclip.com



Works exclusively with oloclip,
the ultimate 3-in-1 lens solution that
enhances your photos and videos!



*LED Light & Tripod not included.